


4.2.16.8 Software Release

Presented by:

David Meyerowitz - Technical Sales Manager EU Duration: 30 minutes + Q&A (approx)



Housekeeping



- Session is being recorded
- Follow up with links to recording and slides will come 24 hours from now
- Audience in Listen Only Mode
- Please type your questions in the Questions window
- We will try and answer all questions during the session. If there is anything we can't answer we will follow up after.

Agenda



- 4.2.16.8 Software Release:
 - Altitude +⁴
 - o IMAX Enhanced
- Q&A

How do I upgrade my unit to 4.2.16.8?



- Release date is next Monday 29th November
- o In the first instance please ask your dealer/distributor who can run the upgrade remotely via our My.Trinnov platform
- Email support@trinnov.com with your serial number and we can perform the upgrade
- Updates may be available via your front panel display/VNC interface but this is not default so has to be enabled by your dealer/distributor
- Its advised you make a backup before performing any over the air upgrade
- Please turn off your amplifiers before starting update




What it is and how does it work?

ALTITUDE PLATFORM



- Additional 4 x discrete Optimized outputs via S/PDIF or AES/EBU free of charge
- Allows AL16 and AL32-816 to achieve these popular, up to 20 channel, layouts:
 - 9.1(4).7, 11.1(4).5 or 9.1(4).4 with biamped LCR
- Not just for additional subs, but that is the intended application
- Can be used for any additional speaker(s)



ALTITUDE PLATFORM



- Why we changed from ADAT:
 - Majority of ADAT converters do not change sample rate automatically
 - Those that did introduced very loud pops and noise during that switch
 - We felt that was not acceptable for the high-end market

ALTITUDE PLATFORM



- The change to S/PDIF:
 - Easier to source than ADAT converters
 - More cost effective
 - More variety to match your intended use
 - More stable operation
 - Auto switch sample rate (unless not specified)



Setup for Altitude 16 and 32

New Configuration:


Speaker/Room Optimizer

Welcome to the Speaker/Room Optimizer process

Here are the first essential steps to control the acoustics in your specific space configuration, within

After defining precisely your speaker layout and placing speakers in your room, you will now be able to

- If it's a new configuration it's advised you use the updated Wizard for both Altitude 16 & 32:
 - New +4 option which will set the output connector
 - Apply to all sources button




Existing configuration Altitude 16



- Add the extra channels required on speaker declaration page (as previous):
 - Output 17 & 18 are on Coax output
 - Output 19 & 20 are on Toslink output

Note:

 When you add or remove a speaker you will automatically loose the previous calibration so please duplicate your Prest before you begin.






Existing configuration Altitude 16



- Add the extra channels required on speaker declaration page (as previous):
 - Output 17 & 18 will be Coax
 - Output 19 & 20 will be Toslink
 - Change Output Connector in Source Config to **Analog EXT**
 - You need to do this for EVERY source including MIC input
- Press Save once complete and you are ready to Re-calibrate






Existing Setups on Altitude³²



- Output connector will need to be changed to the following dependent on model:
 - Analog 1-8 + 9-12 AES Altitude32-88
 - Analog 1-16 + 17-20 AES Altitude32-816
 - Analog 1-24 + 25-28 AES Altitude32-1624
 - Analog 1-32 + 33-36 AES Altitude32-1632
- Press Save once complete and you are ready to Re-calibrate






Important Information

Important Information

- The +4 option brings the maximum sampling rate from 192kHz to 96kHz on all models of Altitude32
- In such situations, the Clock page indicates whether the current sample rate is supported. If not, the sound will not be present
- Any D to A converters not supporting 96kHz will receive sound but will not be played if max sample rate input is exceeded.



Important Information



- If you are already using all 16 x AES/EBU Outputs on Altitude32 how do you use +4?
 - Not available for coming release
 - R&D are working on this and we will update you on the next release
- The example here is mainly active speaker systems, such as Meridian, that take up all the available 16 x AES/EBU outputs.






IMAX Enhanced

IMAX Enhanced

- We are now officially certified after lengthy certification program
- Disney+ recently announced their partnership
- So lots more content on the horizon
- So don't ignore it. Talk to your customers about it. Very recognisable brand to the general public.
- Trinnov's unique implementation allows up to 30 discrete channels using Neural:X upmixer










IMAX Enhanced



- IMAX Mode settings in DTS Decoder options. Can be disabled if required or left to Auto
- IMAX Enhanced Mode is automatically detected and changes the LFE settings as prescribed by DTS
- Bass Management settings not changed. This was our decision as we base our BM settings on speakers not content.
- True-Bass not enabled in our implementation. True-Bass adds bump to frequency response that's designed for soundbars and small speaker kits.





THANK YOU!

